

SHIP-330

User Manual



SHIP-330 (330x0.1lb/150x0.05kg)






Thank you for purchasing the American Weigh SHIP-330 digital shipping scale. Please read all operating instructions carefully before use. Scales are precision measuring devices and should always be handled with proper care. To ensure years of reliable service, keep these simple tips in mind:

- Do not exceed the scale's maximum capacity.
 Overloading your scale can permanently damage it!
- Avoid exposure to extreme heat or cold. Scales perform best at normal room temperature. If temperatures have changed dramatically, calibration and adjustment may be necessary.
- Allow your scale to warm up for 30-60 seconds before performing calibration and adjustment(if available).
- Store your scale in a clean, dry location. Dust, dirt, and moisture can accumulate on the weighing sensors and electronics causing inaccuracy or malfunction.
- Avoid using your scale in close proximity to strong radio wave emitting devices such as computers, cash registers, and cordless phones.
- Always weigh on a flat and level surface, free from vibrations and drafts. The corner of a room is usually the most stable.
- Gently apply all items to be weighed. Do not drop items onto the weighing platform.
- Avoid dropping your scale. The warranty does not cover damage due to rough treatment or overload.
- Check the batteries first if you are having any trouble with your scale. This simple step can remedy most scale issues.
- Do not disassemble your scale. This product contains no user serviceable parts.

I. Part List


- 1. Scale
- 2. Remote Indicator Mounting Hardware
- 3. AA Batteries (x4)
- 4. AC Adapter

II. Key Description



III. Battery Installation

- Before using the scale for the first time, check the battery compartment and remove any plastic insulation strips or packaging that may be in place to prevent battery drainage during shipping/storage.
- If you are replacing the batteries, make sure the positive and negative contacts are properly aligned.



IV. Operation

- Place the scale on a flat, level surface and press the ON/OFF key to turn the scale on.
- 2. Once the start-up process completes and the scale goes to zero you are ready to weigh.
- Place the quantity to be weighed onto the weighing platform.
- Wait a couple seconds for the display to stabilize before taking a weight reading.

V. Changing the Unit of Measure

- Press the MODE key to change the scales displayed unit of measure.
- If the scale is turned off then back on, it will default to the last unit used.
- SHIP-330 Units: kg (kilogram) ➤ oz (ounce) ➤ lb (pound)

VI. Using the Tare Feature

You can use this scale's tare feature to subtract the weight of an empty container or vessel for net weight determination. NOTE: The weight of the container will subtract from the available capacity.

- Place the empty container or vessel on the weighing platform.
- Press the TARE key once. The display will then reset to zero. If the container is removed, it's weight will be displayed as a negative number.
- You may now fill the container with the quantity to be weighed. The display will show the net weight of the contents.
- 4. To return to normal weight display (gross weight),

remove any items from the weighing platform and press the **TARE** key again to re-zero the scale.

VII. Troubleshooting

Problem: Scale will not turn on

Solution: Check the batteries

Problem: Displayed weight fluctuates randomly

 Solution: Make sure your workspace is stable and free of any air currents or vibration

Problem: Displayed weight is inaccurate

Solution: Perform a calibration adjustment

VIII. Error Codes

- OUTZ Zero range has shifted. Perform calibration adjustment. If the problem persists, the load cell may be permanently damaged due to overloading.
- 88888 Maximum capacity exceeded. Remove the extra weight to avoid damaging the load cell.
- L Batteries are low. Replace the batteries.

	SHIP-330
Max. Capacity	330lb / 150kg / 5280oz
Readability	0.1lb / 0.05kg / 2oz
Power	4 x AA Batteries or AC Adapter
	DC 9V 200mA
Platform Dimensions	12 x 15 x 1.37
Warranty	10 Year Limited Warranty



Don't expose scale to moisture



Don't drop or mistreat the scale.



Don't overload the scale. This will permanently damage it!



Don't leave weight on the scale when not in use



Replace battery when the scale displays " + or shows "LO" on the display when powered up