# **V. Proper Care Instructions**



Don't expose scale to moisture





Don't drop or mistreat the scale.




Don't overload the scale. This will permanently damage it!



Don't leave weight on the scale when not in use.



Replace battery when the scale displays " + - " or shows "LO" on the display when powered up



AMWSHIP-150

150 x 0.1lb / 68 x 0.05kg / 150lb x 2oz

AMWSHIP-330S

330 x 0.1lb / 150 x 0.05kg / 330lb x 2oz

User Manual

### I. Operation

For the best results, only operate your scale on a flat and stable surface.

- 1. Insert the included 9V battery into the battery compartment, or plug the AC-Adapter into an available wall outlet and plug the opposite end into the scale.
- 2. Press the "ON/OFF" key to turn the scale on.
- 3. Wait until the display shows "0.0" (zero) before placing any weight on the scale.
- 4. Carefully place the item(s) to be weighed onto the weighing platform.
- 5. After a few seconds, the weight should stabilize and you can now get your weight reading from the LCD display.
- 6. Using the "MODE" key you can switch between weighing units (lb, kg, lb/oz)

## **II. Tare Weighing**

The Tare button resets the display to zero when weight is on the scale, allowing you to subtract the weight of a container.

- 1. Place the container you wish to use on the platform.
- 2. When the readout stabilizes press the TARE key once.
- 3. The display will reset to zero allowing you to now add items to the container and obtain the weight of just the contents (net weight).

### III. Clock Setup

This scale has a built in clock feature.

- 1. When in clock mode (no weighing), press the SET button once "Hour" will begin to flash.
- 2. Press the "\( \blacktriangle \)" button to increase the hour digit (hold to go faster).
- 3. When you are finished setting the hour, press the SET key again.
- 4. "Minute" will begin to flash on the LCD.
- 5. Press the "\( \Lambda \)" button to increase the minute digit (hold to go faster).
- If you do not need to change any other settings, you can keep pressing the SET key until you return to clock mode.

## IV. Specifications

Model	AMWSHIP-150	AMWSHIP-330S
Capacity	150lb / 68kg	330lb / 150kg
Resolution	0.1lb / 0.05kg / 2oz	0.1lb / 0.05kg / 2oz
Weighing Units	pounds (lb), kilograms (kg), pound & ounce (lb/oz)	
Display	Blue Backlit LCD	
Platform Dimensions (inches)	11.25 x 11.75 x 1.37	
Power	1 (one) 9V or AC-Adapter (both included)	
Weight		